

SHOW PRO INDUSTRIES

P.O. Box 1235, Springtown, TX 76082 / (817)523-4055 / (817)220-5117 fax

Show Pro Industries would like to thank you for purchasing a Ranch Sorter™ Training package. Every effort has been taken to provide you with a quality product designed to provide years of trouble-free service.

The Ranch Sorter™

Packing List:

Flag Model (standard)

- control box
- remote control w/ STEPPER technology
- 400' flat-braid nylon rope
- trainer flag
- return pulley w/ mount
- universal mounting bracket
- installation instructions



INSTALLATION INSTRUCTIONS:

Flag Model:

1. **Mount control box:**
Securely attach control box on one side of arena. It should be mounted so pulleys on bottom of box are approximately 45" from ground.

(Refer to enclosed mounting bracket instructions to install bracket.)
2. **Mount return pulley:**
Mount off-side return pulley on opposite side of arena in horizontal position approximately 45" from ground.
3. **Install flat-braid rope:**
To install flat braid rope, start in center of arena. Take one end of rope around off-side pulley, across arena, around pulley on bottom of control box, and back to center of arena. Tie one end of rope to left side of flag and other end to right side of flag while removing slack. Cut off extra line.
4. **Apply power:**
Plug Ranch Sorter into grounded 120VAC, 3-prong outlet. Always unplug unit when not in use. *EURO MODELS: 240VAC/50Hz
5. **Power on Remote:**
A power button is located on the right side of the remote control pouch. The power indicator light does NOT illuminate when power is ON. It only illuminates when you press the directional switches on the remote control or the Stepper switches.
(Refer to Performance Package instructions on page 6.)
6. **Operate system:**
Take a minute to experiment with the system. On side of control box, adjust SPEED dial to "50", and RATE dial to "10". Attach remote control to your wrist, and fingerplate on your index (pointer) finger. Using your thumb to operate buttons, move flag

end to end. Make any adjustments (tighten rope, adjust speeds, etc).

Once comfortable with the controls, you are ready to introduce your horse to the Ranch Sorter. We recommend working at slow speeds until both horse and rider are acclimated.

ADDITIONAL FEATURES:


- * Soft-start acceleration: Progressive acceleration ramp
- * Superior radio system: Better range, less interference.
- * Large drive system: Heavy-duty industrial components
- * Weather-tight NEMA enclosure
- *Dynamic braking

Thank you for choosing.....


SHOW PRO INDUSTRIES

P.O. Box 1235, Springtown, TX 76082 / (817)523-4055 / (817)220-5117 fax


FRONT VIEW - FLAG MODEL




OVERHEAD VIEW - FLAG MODEL



HOLE LOCATIONS FOR MOUNTING RANCH
SORTER TO FIXED PANEL



OPPOSITE SIDE OF ARENA



PERFORMANCE PACKAGE SYSTEM UPGRADE

Your Ranch Sorter is now equipped with the all new Performance Package. This full system upgrade enhances your training experience by giving the rider the ability to make speed adjustments from horseback using STEPPER technology, and an ultra-high performance remote control radio package. This new “state of the art” operator interface provides many advantages over other remote control systems. These include user programmable functions, instant response, extended range, reduced power consumption, and a flush mount antenna system.

STEPPER TECHNOLOGY:

Stepper Technology refers to the process of changing speeds from horseback using the wrist mounted remote control. After setting your base speeds on the Ranch Sorter control



box, the rider can then adjust speed(s) by pressing the SPEED UP or SPEED DOWN buttons located top of the remote control pouch. Each press of either button will result in a 10% STEP in speed; with a total number of 10 STEPS available. Cycling power on the Ranch Sorter control box will reset the STEPPER back to center: (-5 steps) center (+5steps)

REMOTE CONTROL:

The remote control includes an easily replaceable 9 volt battery and is ready to operate once your Ranch Sorter is installed. As with any electronic device, the remote control should be stored in a cool, dry location to enhance battery life and prevent corrosion. Should the remote control become wet, damage may be prevented by immediately removing the battery and leaving the battery door off in a warm, low humidity location for several hours. The battery should also be removed during extended storage periods exceeding 2 to 3 months. Direct replacement remote controls are readily available should the original unit become lost or damaged.


A power button is located on the right side of the remote control pouch. The power indicator light does NOT illuminate when power is ON. It only illuminates when you press the directional switches on the remote control or the Stepper switches. Battery

requires replacement if light is on continuously, or does not illuminate when control buttons are pressed. ALWAYS turn power button OFF when not in use.

PAIRING (PROGRAMMING):

At times it is desirable to operate multiple Ranch Sorters' in close proximity without the remote controls' cross-communicating. This requires a simple PAIRING procedure to shift the radio package to an alternate frequency. The following procedure outlines the pairing (programming) process which requires opening the Ranch Sorter drive box **with power applied**. Care must be taken to avoid contact with live circuits or electric shock may occur. Show Pro Industries accepts no responsibility for damage or injury resulting from contact with live electrical circuits. **PROGRAM RADIOS AT YOUR OWN RISK.**

- 1) Begin by opening the lid on the Ranch Sorter drive box. This is accomplished using a blade screw driver on the ¼ turn lid latch. Once open, the radio receiver is located in the top-center of the control box (drawing 1). Using drawing 1 as a guide, identify the black PAIR button located near the center of the receiver circuit board.



- 2) Remove the wireless remote control from the canvas/Velcro pouch. Using drawing 2 as a guide locate the pairing hole in the upper left corner of the remote control case. A small pin will be required to access the pairing switch.
- 3) With power applied to the Ranch Sorter drive box, press and release the black PAIR button on the radio receiver board. A yellow PAIR indicator will illuminate on the receiver board indicating the receiver is searching for the remote control. Next, press and release the PAIR button on the remote control using a small pin. You should now see the yellow PAIR indicator flash and the green RF GOOD indicator illuminate. Wait for both indicators to turn off before pressing any buttons or switches.

- 4) Pairing is complete once both indicators turn off. Test for proper operation by pressing the remote control RUN buttons. The green RF GOOD indicator should illuminate each time a RUN button is pressed. Close Ranch Sorter lid being careful to fully engage lid latch to prevent possible damage from water/dirt entering control box. Reinstall remote control case into Velcro pouch.

IMPORTANT SAFEGUARDS:

1. Electrical enclosure (control box) should be protected with a non-metal roof or shield. This not only protects the paint finish but also keeps rubber components (gasket, boots, antenna, etc.) from drying out.
2. **Warning:** Electric shock or malfunction could occur if power cord or plug is damaged in any way. Do not work Ranch Sorter in rain – or allow cord or plug to lie in water
3. Always use properly grounded 120VAC electrical outlet.
4. Do not operate Ranch Sorter if control box, or any of its components are damaged in any way, or after malfunction.
5. Use Ranch Sorter only as intended and described in literature.
6. Always unplug Ranch Sorter when through working each day.
7. Do not allow flag to run into ends, or damage may occur to electronics, rope, or both.

TROUBLE SHOOTING

Problem:

1. Ranch Sorter will not operate using remote control or manual switch.

Solution:

Make sure there is power to machine. Check 4A fuse.

-
2. Ranch Sorter will operate using manual switch but not remote control.

Check battery in remote control. Be sure antenna & receptacle aren't damaged.

-
3. There's a "clicking" noise but Ranch Sorter won't run.

Fuse is blown.
replace fuse (4 amp, 250 v., fast blow).

NOTE: The remote control, worn on the rider's wrist, has a 9-volt battery in the plastic case inside the pouch. The battery must be changed on a regular basis.

LIMITED WARRANTY

The following warranty is in lieu of all other warranties, expressed, implied or statutory, including but not limited to any implied warranty of merchantability or fitness for a particular purpose.

All new products sold by Show Pro Industries are warranted against defects in material and workmanship for two (2) years from the date of original purchase. During the warranty period, Show Pro Industries will repair, or at its option replace without charge, any SPI product (excluding normal wear items), providing it is returned to the factory, shipping prepaid, and is proven to be defective during the subsequent factory inspection. The warranty period for products repaired after expiration of new product warranty, as stated above, is limited to the repair portion and is valid for 90 days from date of reshipment to customer. All warranties, expressed or implied, are void if product is damaged by accident, misuse or modification in the absence of written authority from Show Pro Industries.

SHOW PRO INDUSTRIES

P.O. Box 1235, Springtown, TX 76082 / (817)523-4055 / (817)220-5117 fax
email: showpro@flash.net / www.procutter.com

